## SOP

## **Bi Sulfite Change-Out**

## Removal of empty tote

Turn water hose on to run through the drain while this is being done.

Verify tote discharge valve and feed line are closed.

Begin to disconnect the feed line from the tote.

After feed line is disconnected put over the grate for the drain.

Replace the cap on the tote discharge valve and lid on the top.

Use the pallet jack to remove old/empty tote and put new/full tote back in place.

## Reconnecting full tote

After full tote is in place verify that the tote discharge valve is closed.

Remove the cap from the discharge valve and any foil that is sealing it.

Reconnect the feed line to the discharge valve.

Open the lid of the tote to vent and keep tote from collapsing.

Slowly open discharge valve and make sure there are no leaks.

Rinse down work area.