Emergency Event:	WW-9 TREATMENT PLANT EQUIPMENT FAILURE
Emergency Trigger:	Electrical loss or malfunction alarms via SCADA systemEquipment failure alarms via SCADA system
Risks:	Operations Spill/Contamination NPDES Permit violation

Actions Required:

- Conduct impact assessment
- Investigate failure, determine cause, and appropriate repairs required
- Arrange for necessary repair works
- If failure results in sewage overflow or spill, Follow SOP: Emergency Response to Sanitary Sewer Overflow/Spill

Discretionary Actions:

Secure other back-up equipment (Bypass pumps)

Internal Contacts:

- Utilities Director (ER Lead)
- Asst. Utilities Director (Alternate ER Lead)
- Environmental Manager
- City Manager/Asst. City Manager
- Public Information Officer

External Contacts:

- EPD
- Health Department

Follow Up Actions Required:

- Detailed Written report (internal to City)
- · Written report to external agencies (EPD), if required